



## **A.u.S. Spielgeräte GmbH**

A-1210 Wien Scheydgasse 48  
Tel.+43-(0)1-271 66 00 Fax. +43-(0)1-271 66 00 75  
www.aus.at

### Fehlercode für Geldspielgerät Bally S5500

| Code | Fehler  |
|------|---|
| 20   | Coin not Coin-in jam                          |
| 21   | sensed by drop optic                          |
| 22   | Coin Reverse                                  |
| 23   | Inappropriate coin-in                         |
| 24   | Coin Reverse                                  |
| 30   | Hopper overpay                                |
| 31   | Hopper Coin-Out Jam                           |
| 32   | Hopper Empty                                  |
| 33   | Reset during Payout                           |
| 41   | Reel #1                                       |
| 42   | Reel #2                                       |
| 43   | Reel #3                                       |
| 44   | Reel #4                                       |
| 45   | Reel #5                                       |
| 50   | Slot Door Open                                |
| 54   | Drop Door Open                                |
| 60   | Reset During Bill Change                      |
| 65   | Mechanical Meter Disconnect                   |
| 70   | Door Opened During Reelspin                   |
| 71   | Reel #1                                       |
| 72   | Reel #2                                       |
| 73   | Reel #3                                       |
| 74   | Reel #4                                       |
| 75   | Reel #5                                       |
| 80   | Rom Cheksum error or supplement version error |
| 81   | Battery voltage low                           |
| 82   | Door open During Power Down                   |
| 83   | Safe Ram Error                                |
| 84   | Ram Error                                     |
| 90   | Display Error                                 |
| 91   | Communication Error                           |