

Part 2 - Contents

| | |
|---|----|
| 1. Introduction | 4 |
| 2. Notation..... | 4 |
| 2.1 Key | 5 |
| 3. Command List..... | 6 |
| 3.1 Header 255 - Factory set-up and test..... | 6 |
| 3.2 Header 254 - Simple poll..... | 6 |
| 3.3 Header 253 - Address poll..... | 6 |
| 3.4 Header 252 - Address clash..... | 6 |
| 3.5 Header 251 - Address change..... | 6 |
| 3.6 Header 250 - Address random..... | 6 |
| 3.7 Header 249 - Request polling priority..... | 7 |
| 3.8 Header 248 - Request status..... | 7 |
| 3.9 Header 247 - Request variable set..... | 7 |
| 3.10 Header 246 - Request manufacturer id | 8 |
| 3.11 Header 245 - Request equipment category id | 8 |
| 3.12 Header 244 - Request product code..... | 8 |
| 3.13 Header 243 - Request database version | 8 |
| 3.14 Header 242 - Request serial number | 9 |
| 3.15 Header 241 - Request software revision..... | 9 |
| 3.16 Header 240 - Test solenoids..... | 9 |
| 3.17 Header 239 - Operate motors..... | 10 |
| 3.18 Header 238 - Test output lines | 10 |
| 3.19 Header 237 - Read input lines | 10 |
| 3.20 Header 236 - Read opto states | 11 |
| 3.21 Header 235 - Read last credit or error code | 11 |
| 3.22 Header 234 - Issue guard code..... | 11 |
| 3.23 Header 233 - Latch output lines | 12 |
| 3.24 Header 232 - Perform self-check | 12 |
| 3.25 Header 231 - Modify inhibit status..... | 12 |
| 3.26 Header 230 - Request inhibit status..... | 13 |
| 3.27 Header 229 - Read buffered credit or error codes | 13 |
| 3.28 Header 228 - Modify master inhibit status | 15 |
| 3.29 Header 227 - Request master inhibit status..... | 15 |
| 3.30 Header 226 - Request insertion counter..... | 16 |
| 3.31 Header 225 - Request accept counter..... | 16 |
| 3.32 Header 224 - Dispense coins..... | 16 |
| 3.33 Header 223 - Dispense change..... | 17 |
| 3.34 Header 222 - Modify sorter override status | 17 |
| 3.35 Header 221 - Request sorter override status | 18 |
| 3.36 Header 220 - One-shot credit..... | 18 |
| 3.37 Header 219 - Enter new PIN number..... | 18 |
| 3.38 Header 218 - Enter PIN number..... | 19 |
| 3.39 Header 217 - Request payout high / low status | 19 |
| 3.40 Header 216 - Request data storage availability | 19 |
| 3.41 Header 215 - Read data block | 21 |
| 3.42 Header 214 - Write data block..... | 21 |
| 3.43 Header 213 - Request option flags..... | 21 |
| 3.44 Header 212 - Request coin position..... | 22 |
| 3.45 Header 211 - Power management control..... | 22 |
| 3.46 Header 210 - Modify sorter paths..... | 23 |
| 3.47 Header 209 - Request sorter paths..... | 23 |
| 3.48 Header 208 - Modify payout absolute count..... | 23 |
| 3.49 Header 207 - Request payout absolute count..... | 24 |
| 3.50 Header 206 - Empty payout..... | 24 |
| 3.51 Header 205 - Request audit information block..... | 25 |
| 3.52 Header 204 - Meter control..... | 25 |
| 3.53 Header 203 - Display control..... | 26 |
| 3.54 Header 202 - Teach mode control..... | 26 |
| 3.55 Header 201 - Request teach status | 27 |

| | |
|---|----|
| 3.56 Header 200 - Upload coin data..... | 27 |
| 3.57 Header 199 - Configuration to EEPROM | 28 |
| 3.58 Header 198 - Counters to EEPROM | 28 |
| 3.59 Header 197 - Calculate ROM checksum..... | 29 |
| 3.60 Header 196 - Request creation date..... | 29 |
| 3.61 Header 195 - Request last modification date..... | 30 |
| 3.62 Header 194 - Request reject counter..... | 30 |
| 3.63 Header 193 - Request fraud counter..... | 30 |
| 3.64 Header 192 - Request build code..... | 30 |
| 3.65 Header 191 - Keypad control..... | 30 |
| 3.66 Header 190 - Request payout status | 31 |
| 3.67 Header 189 - Modify default sorter path | 32 |
| 3.68 Header 188 - Request default sorter path..... | 32 |
| 3.69 Header 187 - Modify payout capacity..... | 32 |
| 3.70 Header 186 - Request payout capacity..... | 32 |
| 3.71 Header 185 - Modify coin id | 33 |
| 3.72 Header 184 - Request coin id | 33 |
| 3.73 Header 183 - Upload window data | 33 |
| 3.74 Header 182 - Download calibration info | 34 |
| 3.75 Header 181 - Modify security setting..... | 34 |
| 3.76 Header 180 - Request security setting..... | 34 |
| 3.77 Header 179 - Modify bank select..... | 35 |
| 3.78 Header 178 - Request bank select..... | 35 |
| 3.79 Header 177 - Handheld function..... | 35 |
| 3.80 Header 176 - Request alarm counter..... | 36 |
| 3.81 Header 175 - Modify payout float | 36 |
| 3.82 Header 174 - Request payout float | 36 |
| 3.83 Header 173 - Request thermistor reading..... | 36 |
| 3.84 Header 172 - Emergency stop..... | 37 |
| 3.85 Header 171 - Request hopper coin..... | 37 |
| 3.86 Header 170 - Request base year..... | 37 |
| 3.87 Header 169 - Request address mode | 37 |
| 3.88 Header 168 - Request hopper dispense count..... | 38 |
| 3.89 Header 167 - Dispense hopper coins..... | 38 |
| 3.90 Header 166 - Request hopper status..... | 38 |
| 3.91 Header 165 - Modify variable set | 39 |
| 3.92 Header 164 - Enable hopper..... | 39 |
| 3.93 Header 163 - Test hopper..... | 39 |
| 3.93.1. Flag Explanation..... | 40 |
| 3.93.1.1. Absolute maximum current exceeded..... | 40 |
| 3.93.1.2. Payout timeout occurred..... | 40 |
| 3.93.1.3. Motor reversed during last payout to clear a jam..... | 41 |
| 3.93.1.4. Opto fraud attempt, path blocked during idle | 41 |
| 3.93.1.5. Opto fraud attempt, short-circuit during idle | 41 |
| 3.93.1.6. Opto blocked permanently during payout..... | 41 |
| 3.93.1.7. Power-up detected..... | 41 |
| 3.93.1.8. Payout disabled..... | 41 |
| 3.93.1.9. Opto fraud attempt, short-circuit during payout..... | 41 |
| 3.93.1.10. Single coin mode | 41 |
| 3.93.1.11. Use other hopper for change..... | 41 |
| 3.93.1.12. Opto fraud attempt, finger / slider mis -match | 42 |
| 3.93.1.13. Motor reverse limit reached..... | 42 |
| 3.93.1.14. Inductive coil fault..... | 42 |
| 3.93.1.15. NV memory checksum error | 42 |
| 3.93.1.16. PIN number mechanism..... | 42 |
| 3.93.1.17. Power-down during payout..... | 42 |
| 3.93.1.18. Unknown coin type paid | 42 |
| 3.93.1.19. PIN number incorrect..... | 42 |
| 3.93.1.20. Incorrect cipher key..... | 43 |
| Header 162 - Modify inhibit and override registers | 43 |
| 3.94 Header 161 - Pump RNG..... | 43 |

| | |
|---|----|
| 3.95 Header 160 - Request cipher key | 43 |
| 3.96 Header 159 - Read buffered bill events | 44 |
| 3.97 Header 158 - Modify bill id | 44 |
| 3.98 Header 157 - Request bill id | 44 |
| 3.99 Header 156 - Request country scaling factor..... | 45 |
| 3.100 Header 155 - Request bill position..... | 45 |
| 3.101 Header 154 - Route bill | 45 |
| 3.102 Header 153 - Modify bill operating mode..... | 46 |
| 3.103 Header 152 - Request bill operating mode..... | 46 |
| 3.104 Header 151 - Test lamps..... | 46 |
| 3.105 Header 150 - Request individual accept counter..... | 46 |
| 3.106 Header 149 - Request individual error counter | 47 |
| 3.107 Header 148 - Read opto voltages..... | 47 |
| 3.108 Header 147 - Perform stacker cycle | 47 |
| 3.109 Header 146 - Operate bi-directional motors | 48 |
| 3.110 Header 145 - Request currency revision | 48 |
| 3.111 Header 144 - Upload bill tables | 48 |
| 3.112 Header 143 - Begin bill table upgrade..... | 49 |
| 3.113 Header 142 - Finish bill table upgrade..... | 49 |
| 3.114 Header 141 - Request firmware upgrade capability | 49 |
| 3.115 Header 140 - Upload firmware | 49 |
| 3.116 Header 139 - Begin firmware upgrade | 49 |
| 3.117 Header 138 - Finish firmware upgrade..... | 49 |
| 3.118 Header 137 - Switch encryption code..... | 50 |
| 3.119 Header 136 - Store encryption code..... | 50 |
| 3.120 Header 135 - Set accept limit | 50 |
| 3.121 Header 134 - Dispense hopper value | 51 |
| 3.122 Header 133 - Request hopper polling value..... | 51 |
| 3.123 Header 132 - Emergency stop value..... | 52 |
| 3.124 Header 131 - Request hopper coin value..... | 52 |
| 3.125 Header 130 - Request indexed hopper dispense count..... | 52 |
| 3.126 Header 129 - Read barcode data | 52 |
| 3.127 Header 4 - Request comms revision..... | 53 |
| 3.128 Header 3 - Clear comms status variables | 53 |
| 3.129 Header 2 - Request comms status variables..... | 53 |
| 3.130 Header 1 - Reset device..... | 54 |

1. Introduction

This document gives a definitive list of all cctalk commands so far. They are listed in reverse header number order for the following reasons...

- Historical. Headers were defined from the top downwards. The most recent additions to the specification are towards the end.
- Speed. A manual search knowing the header number is quick.

If you are only interested in a specific type of peripheral and are unsure as to which commands need to be implemented then refer to Appendix 1 which is a master command cross-reference. For example, you can find all commands that might be used on a coin acceptor.

There is no requirement on a cctalk peripheral to implement the full command set. Refer to specific product documentation from each manufacturer to find the level of support.

2. Notation

The **master** device initiates a communication sequence and sends a command or a request for data. The words *master*, *host* and *server* are interchangeable in this respect. Example masters include a PC, VMC and MPU.

The **slave** device responds to a command with an acknowledge or a message containing 1 or more data bytes. The words *slave*, *guest*, *client* and *peripheral* are interchangeable in this respect. Example slaves include a 'Coin Acceptor', 'Payout' and 'Bill Validator'.

Transmitted data in the command description is data sent from the master to the slave.

Received data in the command description is data received by the master from the slave. Note that due to the bi-directional data line, the master may also loop-back its own transmitted data first - this is not shown.

For clarity, the full cctalk message packet is not shown in the command description - only the data fields. The destination and source address (if used) will be set accordingly. The length byte will reflect the size of the data packet and the checksum will be calculated for the complete message. The value of the header byte is shown separately for each command.

Values between square brackets, [XXX], indicate message bytes. All data bytes are shown in decimal unless otherwise stated. The bytes on the left are those transmitted or received first.

Some data bytes are shown in binary, e.g. XXXX | 1100 - a total of 8 bits, the lower 4 bits of which are specified.

1 indicates a bit set to logic one (set)
0 indicates a bit set to logic zero (cleared)
X indicates a bit in a don't care or undefined state
| indicates a field separator (for display clarity only)

Note that **within** a byte, the MSB (most significant bit) is on the left and the LSB (least significant bit) is on the right.

Bulk transfer convention : Data can be **downloaded** to the master from the slave, and **uploaded** to the slave from the master. The slave devices are located 'uphill' in cctalk parlance.

2.1 Key

| | |
|------------|---|
| <none> | No data bytes. The rest of the message packet is still transmitted or received though. |
| <variable> | One or more data bytes |
| ACK | The standard cctalk ACK message |
| ASCII | An ASCII string received as characters e.g. 'H' 'e' 'l' 'l' 'o' |

3. Command List

3.1 Header 255 - Factory set-up and test

Transmitted data : <variable>

Received data : ACK or <variable>

This command is reserved for functions needed during the manufacture of a product and is not intended for general use. Every manufacturer can define their own set of functions buried behind this header number.

3.2 Header 254 - Simple poll

Transmitted data : <none>

Received data : ACK

This command can be used to check that the slave device is powered-up and working. No data is returned other than the standard ACK message and no action is performed. It can be used at EMS (Early Morning Start-up) to check that the slave device is communicating. A timeout on this command indicates a faulty or missing device, or an incorrect bus address or baud rate.

***** All cctalk peripherals must reply to a simple poll *****

3.3 Header 253 - Address poll

Refer to the section on MDCES.

3.4 Header 252 - Address clash

Refer to the section on MDCES.

3.5 Header 251 - Address change

Refer to the section on MDCES.

3.6 Header 250 - Address random

Refer to the section on MDCES.

3.7 Header 249 - Request polling priority

Transmitted data : <none>

Received data : [units] [value]

This is an indication by a device of the recommended polling interval for buffered credit information. Polling a device at an interval longer than this may result in lost credits.

[units]

0 - special case, see below

1 - ms

2 - x10 ms

3 - seconds

4 - minutes

5 - hours

6 - days

7 - weeks

8 - months

9 - years

If units = 0 and value = 0 then refer to the product manual for polling information

If units = 0 and value = 255 then the device uses a hardware REQUEST POLL line

3.8 Header 248 - Request status

Transmitted data : <none>

Received data : [status]

This command reports the status of a coin acceptor.

<<< Refer to Table 4 >>>

3.9 Header 247 - Request variable set

Transmitted data : <none>

Received data : <variable>

This command requests variable data from a slave device. Some of the returned variables may be useful to a host application and some may not, but any data is application specific. Refer to the product manual for more details.

On a Bill Validator

2 variables have now been universally defined for bill validator products...

[variable 1] - No. of bill types concurrently supported (typically 16)

[variable 2] - No. of banks supported (typically 1)

3.10 Header 246 - Request manufacturer id

Transmitted data : <none>

Received data : ASCII

The manufacturer's unique identification string is returned.

For example, 'Money Controls'. Alternatively, it may appear in abbreviated format e.g. 'MCI'.

<<< Refer to Table 6 >>>

3.11 Header 245 - Request equipment category id

Transmitted data : <none>

Received data : ASCII

The standard equipment category identification string is returned.

<<< Refer to Table 1 >>>

3.12 Header 244 - Request product code

Transmitted data : <none>

Received data : ASCII

The product code is returned. No restriction on format.

The complete product identification string can be determined by using 'Request product code' followed by 'Request build code'.

3.13 Header 243 - Request database version

Transmitted data : <none>

Received data : [calibration database no.]

This command retrieves a database number from 1 to 255 which may be used for remote coin programming.

A database number of 0 indicates remote coin programming is not possible.

3.14 Header 242 - Request serial number

Transmitted data : <none>

Received data : [serial 1] [serial 2] [serial 3]

This command returns the device serial number in binary format and for most products a 3 byte code is sufficient.

serial 1 = LSB

24-bit serial number in decimal = [serial 1] + 256 * [serial 2] + 65536 * [serial 3]
Range 0 to 16,777,215 (~16 million)

Adding an extra data byte will increase the largest product serial number to 4,294,967,295 (~4 billion).

3.15 Header 241 - Request software revision

Transmitted data : <none>

Received data : ASCII

The slave device software revision is returned. There is no restriction on format - it may include full alphanumeric characters.

Any change to slave software, however minor, should be reflected in this revision code.

3.16 Header 240 - Test solenoids

Transmitted data : [bit mask]

Received data : ACK

Implemented on slave devices which use solenoids.

The solenoids are pulsed for a set time. The bit mask indicates which solenoids to operate.

[bit mask]

The following bits have been defined for a coin acceptor :

Bit 0 - Accept gate solenoid. 0 = no action, 1 = pulse.

Bit 1 - Sorter solenoid 1

Bit 2 - Sorter solenoid 2

Bit 3 - Sorter solenoid 3

The slave ACK is returned **after** the solenoid de-activates, perhaps 500ms later.

3.17 Header 239 - Operate motors

Transmitted data : [bit mask]

Received data : ACK

Implemented on slave devices which use motors.

[bit mask]

Each bit controls a motor. 0 = motor off, 1 = motor on.

3.18 Header 238 - Test output lines

Transmitted data : [bit mask]

Received data : ACK

Implemented on slave devices which have an output port.

Various output lines are pulsed. The bit mask indicates which lines to pulse. The length of the pulses is product specific.

[bit mask]

Each bit refers to an output line. 0 = no action, 1 = pulse.

The slave ACK is returned after the line de-activates.

3.19 Header 237 - Read input lines

Transmitted data : <none>

Received data : <variable>

Implemented on slave devices which have an input port.

This command requests various input data from a slave device and is an excellent debugging tool. It can be used to check the operation of switches, push buttons, connector signals, processor input lines etc.

Refer to the product manual for more details.

3.20 Header 236 - Read opto states

Transmitted data : <none>

Received data : [bit mask]

Implemented on slave devices which have optos.

This command is used to check the state of various opto devices in the slave device. Refer to the product manual for more details.

[bit mask]

Each bit refers to an opto. 0 = opto clear, 1 = opto blocked.

3.21 Header 235 - Read last credit or error code

<<< Obsolete command >>>

Refer to 'Read buffered credit or error codes' for coin acceptors.

Refer to 'Read buffered bill events' for bill validators.

Format (a)

Transmitted data : <none>

Received data : [coin position]

Format (b)

Transmitted data : <none>

Received data : [0] [error code]

Format (c)

Transmitted data : <none>

Received data : [coin position] [sorter path]

3.22 Header 234 - Issue guard code

<<< Obsolete command >>>

Transmitted data : <none>

Received data : ACK

From earlier specifications...

Some commands may be protected by a guard code to improve the reliability in noisy environments. For example, using a command which latches output signals may result in electrical component damage in certain situations. Relying on a single 8-bit checksum to ensure data integrity may not be wise in extremely noisy environments. Therefore, the latch command can be disabled unless it occurs within 50ms (for example) of the guard code command being issued. The slave device will therefore only respond if 2 different commands are received correctly and close together - massively reducing the chances of a random fail.

The reliability of cctalk in a wide range of actual operating environments is now respected by many manufacturers. There is no need for the guard code command.

3.23 Header 233 - Latch output lines

Transmitted data : [bit mask]
Received data : ACK

Implemented on slave devices which have an output port.

Various output lines are latched. The bit mask indicates which lines to latch. Polarities and bit mask interpretation will be detailed in the product manual.

3.24 Header 232 - Perform self-check

Format (a)
Transmitted data : <none>
Received data : [fault code]

Format (b)
Transmitted data : <none>
Received data : [fault code] [extra info]

This command instructs the peripheral device to perform a self-check, i.e. a full diagnostic test without user intervention. The actual level of testing is decided by the slave rather than the host and a fault code is returned. Some slave devices support an additional byte of information for certain fault codes.

Where more than one fault exists on a product, faults will be reported in priority order. Once one fault is fixed, the next fault will be reported. The time to execute this command should be made clear in the product manual.

<<< Refer to Table 3 >>>

3.25 Header 231 - Modify inhibit status

Transmitted data : [inhibit mask 1] [inhibit mask 2]
Received data : ACK

This command sends an individual inhibit pattern to a coin acceptor or bill validator. With a 2 byte inhibit mask, up to 16 coins or bills can be inhibited or enabled.

[inhibit mask 1]
Bit 0 - coin / bill 1
...
Bit 7 - coin / bill 8

[inhibit mask 2]
Bit 0 - coin / bill 9
...
Bit 7 - coin / bill 16

0 = coin / bill disabled (inhibited)
1 = coin / bill enabled (not inhibited)

The product manual should make clear whether these changes are permanent (stored in non-volatile memory) or temporary (stored in RAM).

3.26 Header 230 - Request inhibit status

Transmitted data : <none>
Received data : [inhibit mask 1] [inhibit mask 2]

This command requests an individual inhibit pattern from a coin acceptor or bill validator.

See 'Modify inhibit status' for more details.

3.27 Header 229 - Read buffered credit or error codes

Transmitted data : <none>
Received data : [event counter]
 [result 1A] [result 1B]
 [result 2A] [result 2B]
 [result 3A] [result 3B]
 [result 4A] [result 4B]
 [result 5A] [result 5B]

This command returns a past history of event codes for a coin acceptor in a small data buffer. This allows a host device to poll a coin acceptor at a rate lower than that of coin insertion and still not miss any credits or other events.

The standard event buffer size is 10 bytes which at 2 bytes per event is enough to store the last 5 events.

A new event ripples data through the return data buffer and the oldest event is lost.

For example, consider a 5 event buffer :

result 5A ⇒ lost

result 5B ⇒ lost

result 4A ⇒ result 5A

result 4B ⇒ result 5B

result 3A ⇒ result 4A

result 3B ⇒ result 4B

result 2A ⇨ result 3A
 result 2B ⇨ result 3B

result 1A ⇨ result 2A
 result 1B ⇨ result 2B

new result A ⇨ result 1A
 new result B ⇨ result 1B

An event counter is used to indicate any new events and this must be compared at each poll to the last known value.

| event counter - last event counter | Stored in result... |
|---------------------------------------|---------------------------------|
| 0 | - |
| 1 | 1 |
| 2 | 1, 2 |
| 3 | 1, 2, 3 |
| 4 | 1, 2, 3, 4 |
| 5 | 1, 2, 3, 4, 5 |
| 6+ | 1, 2, 3, 4, 5 & others are lost |

[event counter]
 0 (power-up or reset condition)
 1 to 255 - event counter

[result A]
 1 to 255 - credit
 0 - error code

[result B] for credits
 0 - no sorter supported
 1 to 8 - sorter path

[result B] for error codes
 <<< Refer to Table 2 >>>

The event counter is incremented every time a new credit or error is added to the buffer. When the event counter is at 255 the next event causes the counter to change to 1. The only way for the counter to be 0 is at power-up or reset. This provides a convenient signalling mechanism to the host machine that a major fault has occurred.

Examples

| event counter | last event counter | new events |
|---------------|--------------------|-----------------------------|
| 23 | 23 | 0 |
| 104 | 102 | 2 |
| 1 | 255 | 1 |
| 3 | 253 | 5 |
| 54 | 48 | <i>one lost event</i> |
| 0 | 67 | <i>unknown - power fail</i> |

The result codes are stored in a 2 byte format. If the first result code (result A) is zero then this is a reject or error event rather than a coin credit and the reject / error code is stored in result B. If the first result code is non-zero then the value indicates the type of coin accepted (usually 1 to 12 or 1 to 16) and the second result code (result B) is the sorter route the coin went down. Sorter routes are typically 1 to 4 or 1 to 8 with 0 reserved for no sorter operation.

3.28 Header 228 - Modify master inhibit status

Transmitted data : [XXXXXXXX | master inhibit status]

Received data : ACK

[master inhibit status]

Bit 0 only is used.

0 - master inhibit active

1 - normal operation

This command changes the master inhibit status in the slave device. In a coin acceptor, if the master inhibit is active then no coins can be accepted. Likewise for a bill validator.

The product manual should make clear whether this change is permanent (stored in non-volatile memory) or temporary (stored in RAM).

3.29 Header 227 - Request master inhibit status

Transmitted data : <none>

Received data : [XXXXXXXX | master inhibit status]

This command requests the master inhibit status in the slave device.

Refer to the 'Modify master inhibit status' command for polarity.

3.30 Header 226 - Request insertion counter

Transmitted data : <none>

Received data : [count 1] [count 2] [count 3]

count 1 = LSB

This command returns the total number of coins / bills put through a device.

24-bit counter in decimal = [count 1] + 256 * [count 2] + 65536 * [count 3]

Range 0 to 16,777,215

Restrictions on use and likely accuracy will be made clear in the product manual.

3.31 Header 225 - Request accept counter

Transmitted data : <none>

Received data : [count 1] [count 2] [count 3]

This command returns the total number of coins / bills accepted by a device.

24-bit counter in decimal = [count 1] + 256 * [count 2] + 65536 * [count 3]

Range 0 to 16,777,215

Restrictions on use and likely accuracy will be made clear in the product manual.

3.32 Header 224 - Dispense coins

<<< Obsolete command >>>

This command has been superseded by the ultra-secure 'Dispense hopper coins' command. This obsolete command allows 65,535 coins to be paid out in one go.

Transmitted data : [hopper no.] [no. of coins LSB] [no. of coins MSB]

Received data : ACK or [status code]

[hopper no.]

1, 2, 3 etc.

[status code]

252 - error

253 - not available (incorrect hopper no.)

254 - insufficient coins

255 - busy

This command dispenses a number of coins from the specified hopper.

A status code is only returned if there is a problem. The usual response is an ACK.

Depending on the payout speed, this command may take several minutes to complete. Since the ACK message is returned immediately from the slave device, the 'Request payout status' command should be used to monitor progress.

3.33 Header 223 - Dispense change

<<< Obsolete command >>>

Transmitted data : [coin value LSB] [coin value MSB]

Received data : ACK or [status code]

[coin value]

The actual coin value is a multiple of the 'coin value scaling factor' which may typically be 1, 5 or 10.

[status code]

See 'Dispense coins' for possible status codes.

This command is used to dispense change (coins to a given value) from a changer. It is up to the changer to determine the type and quantity of all coins dispensed. The usual changer algorithm is to dispense the maximum number of highest value coins first, followed by the next highest value etc.

A status code is only returned if there is a problem. The usual response is an ACK. Depending on the payout speed, this command may take several minutes to complete. Since the ACK message is returned immediately from the slave device, the 'Request payout status' command should be used to monitor payout progress.

3.34 Header 222 - Modify sorter override status

Transmitted data : [sorter override bit mask]

Received data : ACK

[sorter override bit mask]

B0 - Sorter Path 1

...

B7 - Sorter Path 8

0 = sorter override to a different or default path

1 = no action, normal sorting

This command allows the sorter override status to be set in a coin acceptor. Each bit represents a sorter path for the accepted coin. A zero overrides that sorter path to another one (possibly the *default* sorter path).

The product manual should make clear whether this change is permanent (stored in non-volatile memory) or temporary (stored in RAM).

3.35 Header 221 - Request sorter override status

Transmitted data : <none>

Received data : [sorter override bit mask]

This command returns the sorter override status in a coin acceptor. Each bit represents a sorter path for the accepted coin. A zero means that the sorter path has an active override.

Refer to the 'Modify sorter override status' command for more details.

3.36 Header 220 - One-shot credit

<<< Obsolete command >>>

Format (a)

Transmitted data : [coin position]

Format (b)

Transmitted data : [coin position] [sorter path]

Format (c)

Transmitted data : [0] [error code]

This is a special case where the slave device fires off a credit or error code without being polled by the host. This method is unsuitable for all multi-drop applications (because of collision risk) and does not support a mechanism for re-transmission in the event of a receive error.

3.37 Header 219 - Enter new PIN number

Transmitted data : [PIN 1] [PIN 2] [PIN 3] [PIN 4]

Received data : ACK

Certain commands can be PIN protected - refer to the product manual for a list of commands which support this feature. The existing pin number can be changed with this command, but as this command is itself PIN protected, the existing PIN number must already have been entered.

If any cctalk command is used with the wrong PIN number (including this command) then there is no response from the slave device.

The PIN number is a 32 bit binary number giving 4,294,967,296 combinations.

Assuming it takes about 50ms per guess, an average of 3.4 years would be needed to crack the code.

A new PIN number of ZERO disables the PIN number mechanism.

3.38 Header 218 - Enter PIN number

Transmitted data : [PIN 1] [PIN 2] [PIN 3] [PIN 4]

Received data : ACK

Certain commands can be PIN protected - refer to the product manual for a list of commands which support this function. The existing pin number can be entered with this command. This needs to be done after each power-up or reset.

If the PIN number entered is incorrect then an ACK should still be returned (after a suitable delay) to make exhaustive searching much harder.

3.39 Header 217 - Request payout high / low status

Format (a)

Transmitted data : <none>

Received data : [level status]

Format (b)

Transmitted data : [hopper no.]

Received data : [level status]

This command allows the reading of high / low level sensors in a payout system. Multiple hoppers are supported if they exist.

Bit 0 - Low level sensor status

0 = higher than or equal to low level trigger

1 = lower than low level trigger

Bit 1 - High level sensor status

0 = lower than high level trigger

1 = higher than or equal to high level trigger

Bit 2 - <reserved>

Bit 3 - <reserved>

Bit 4 - Low level sensor support

0 = feature not supported or fitted

1 = feature supported and fitted

Bit 5 - High level sensor support

0 = feature not supported or fitted

1 = feature supported and fitted

Bit 6 - <reserved>

Bit 7 - <reserved>

The trigger level is usually fixed mechanically.

3.40 Header 216 - Request data storage availability

Transmitted data : <none>

Received data : [memory type]

[read blocks] [read bytes per block]

[write blocks] [write bytes per block]

Some slave devices allow host data to be stored for whatever reason. Whether this service is provided at all can be determined by using this command.

[memory type]

- 0 - volatile (lost on reset)
- 1 - volatile (lost on power-down)
- 2 - permanent (limited use)
- 3 - permanent (unlimited use)

Memory types 0 and 1 are typically implemented in RAM, type 2 in EEPROM (write life cycle between 10K and 10M) and type 3 in battery-backed RAM.

[read blocks]

- 1 to 255 - number of blocks of read data available
- 0 - special case, 256 blocks of read data available

[read bytes]

- 1 to 252 - number of bytes per block of read data
- 0 - special case, no read data service**

[write blocks]

- 1 to 255 - number of blocks of write data available
- 0 - special case, 256 blocks of write data available

[writes bytes]

- 1 to 251 - number of bytes per block of write data
- 0 - special case, no write data service**

Due to variable packet length restrictions in the base protocol, we arrive at the following capacities :

The minimum read capacity is 1 block of 1 byte = 1 byte

The maximum read capacity is 256 blocks of 252 bytes = 64,512 bytes
(98.4% of 64K)

The minimum write capacity is 1 block of 1 byte = 1 byte

The maximum write capacity is 256 blocks of 251 bytes = 64,256 bytes
(98.0% of 64K)

The format of the read data blocks may well be different to the format of the write data blocks, but they should nevertheless be contiguous locations in memory. Since write cycle times (the slave will embody automatic erase cycles if necessary) are usually much longer than read cycle times in permanent memory types, it is sometimes better to read data in one large chunk but write it back in smaller chunks. This ensures command response times are better and multi-drop polling can be *finer grained*.

3.41 Header 215 - Read data block

Transmitted data : [block number]

Received data : <variable>

[block no.]

0 to 255 (1st block number is always zero)

3.42 Header 214 - Write data block

Transmitted data : [block number] <variable>

Received data : ACK

[block no.]

0 to 255 (1st block number is always zero)

The return ACK from the slave device is only sent after a write cycle has been performed. It us up to the host software whether a verify operation is performed by reading back the data and comparing it.

3.43 Header 213 - Request option flags

Transmitted data : <none>

Received data : [option flags]

This command reads option flags (single bit control variables) from a slave device.

On a Coin Acceptor

| Bit Position | 0 | 1 |
|--------------|---------------------------------------|-----------------------------|
| 0 | Credit Code Format : Coin Position | Credit Code Format : CVF |
| 1 | - | - |
| 2 | - | - |
| 3 | - | - |
| 4 | - | - |
| 5 | - | - |
| 6 | - | - |
| 7 | - | - |

For a discussion on CVF refer to Appendix 3.2

Credit codes returned with the 'Read buffered credit or error codes' are usually in 'coin position' format. The code does not reflect the monetary value of the coin but the position it is stored within the memory of the coin acceptor. This position usually corresponds directly to the inhibit position. So 'credit 1' can be inhibited with bit 0 of the inhibit mask, 'credit 2' with bit 1 etc.

On a Bill Validator

| Bit Position | Feature (1 = supported) |
|--------------|---------------------------------|
| 0 | stacker |
| 1 | escrow |
| 2 | individual bill accept counters |
| 3 | individual error counters |
| 4 | non-volatile counters |
| 5 | bill teach facility |
| 6 | bill security tuning |
| 7 | remote bill programming |

3.44 Header 212 - Request coin position

Transmitted data : [credit code]

Received data : [position mask 1] [position mask 2]

This command can be used in coin acceptors to locate the inhibit position of a given coin based on its 'credit code'. The inhibit position ties up with the 'Modify inhibit status' command for inhibiting individual coins. To inhibit the coin, the data returned would need to be inverted before sending back out with the 'Modify inhibit status' command.

[credit code]

The value returned by the 'Read buffered credit or error codes' command.

3.45 Header 211 - Power management control

Transmitted data : [power option]

Received data : ACK

This command can be used to switch slave devices in and out of low power modes if they support power management.

[power option]

0 - normal operation (automatic power switching if supported)

1 - switch to low power mode

2 - switch to full power mode

3 - shutdown

A shutdown normally requires an external reset or a power-down cycle to recover.

3.46 Header 210 - Modify sorter paths

Format (a)

Transmitted data : [coin position] [path]

Received data : ACK

Format (b)

Transmitted data : [coin position] [path 1] [path 2] [path 3] [path 4]

Received data : ACK

This command modifies the sorter path for each coin position in a coin acceptor. Some coin acceptors support multiple sorter paths (override paths) and so a longer version of the command exists. In this case the primary path is the first one specified (path 1).

[coin position]

e.g. 1 to 12, 1 to 16

[sorter path]

e.g. 1 to 8

The product manual should make clear whether this change is permanent (stored in non-volatile memory) or temporary (stored in RAM).

3.47 Header 209 - Request sorter paths

Format (a)

Transmitted data : [coin position]

Received data : [path]

Format (b)

Transmitted data : [coin position]

Received data : [path 1] [path 2] [path 3] [path 4]

This command allows sorter paths to be requested in a coin acceptor.

See the 'Modify sorter paths' command for more details.

3.48 Header 208 - Modify payout absolute count

Format (a)

Transmitted data : [no. of coins LSB] [no. of coins MSB]

Received data : ACK

Format (b)

Transmitted data : [hopper no.] [no. of coins LSB] [no. of coins MSB]

Received data : ACK

This command allows the hopper coin counter (absolute number of coins in the hopper) to be initialised to a known value. Multiple hoppers are supported if they exist.

Some hoppers do not support an absolute count value as they can only count coins dispensed.

3.49 Header 207 - Request payout absolute count

Format (a)

Transmitted data : <none>

Received data : [no. of coins LSB] [no. of coins MSB]

Format (b)

Transmitted data : [hopper no.]

Received data : [no. of coins LSB] [no. of coins MSB]

This command allows the hopper coin counter (absolute number of coins in the hopper) to be requested. Multiple hoppers are supported if they exist.

Some hoppers do not support an absolute count value as they can only count coins dispensed.

3.50 Header 206 - Empty payout

<<< Obsolete command >>>

Transmitted data : [hopper no.]

Received data : ACK or [status code]

[status code]

See 'Dispense coins' for possible status codes.

This command is used to completely empty a coin hopper. The usual response is an ACK - a status code is only returned if there is a problem.

Depending on the payout speed, this command may take several minutes to complete. Since the ACK message is returned immediately from the slave device, the 'Request payout status' command should be used to monitor payout progress.

This command provides an easy way to 'jackpot' a hopper and is best left unimplemented or at the very least PIN number protected.

3.51 Header 205 - Request audit information block

<<< Obsolete command >>>

This command has been tailored to a specific Money Controls product - a changer with 3 hoppers.

Transmitted data : <none>

Received data : [coins in hopper 1A] [coins in hopper 1B]
[coins in hopper 2A] [coins in hopper 2B]
[coins in hopper 3A] [coins in hopper 3B]
[coins to cashbox A] [coin to cashbox B] [coins to cashbox C]
[coins accepted A] [coins accepted B] [coins accepted C]
[coins rejected A] [coins rejected B] [coins rejected C]
[coins paid hop. 1A] [coins paid hop. 1B] [coins paid hop. 1C]
[coins paid hop. 2A] [coins paid hop. 2B] [coins paid hop. 2C]
[coins paid hop. 3A] [coins paid hop. 3B] [coins paid hop. 3C]
[value to cashbox A] [value to cashbox B]
[value to cashbox C] [value to cashbox D]
[coin value scaling factor]

Counter designator A denotes the LSB.

The cashbox value is sent in multiples of the 'coin value scaling factor'.

3.52 Header 204 - Meter control

Format (a) - set meter to value

Transmitted data : [0] [count 1] [count 2] [count 3]

Received data : ACK

Format(b) - increment meter

Transmitted data : [1]

Received data : ACK

Format (c) - decrement meter

Transmitted data : [2]

Received data : ACK

Format (d) - reset meter

Transmitted data : [3]

Received data : ACK

Format (e) - read meter

Transmitted data : [4]

Received data : [count 1] [count 2] [count 3]

meter value = [count 1] + 256 * [count 2] + 65536 * [count 3]

This meter command is designed for test purposes only (e.g. counting coins on a life-test jig). **It is not secure enough to be used in an auditing environment.**

3.53 Header 203 - Display control

Format (a) - send character (append)

Transmitted data : [0] [char]

Received data : ACK

Format (b) - clear display

Transmitted data : [1]

Received data : ACK

Format (c) - send control code

Transmitted data : [2] [control code]

Received data : ACK

Format (d) - send string (append)

Transmitted data : [3] [char 1] [char 2] [char 3]...

Received data : ACK

Format (e) - request display size

Transmitted data : [4]

Received data : [characters] [lines]

This is a method for controlling a simple LCD display, typically 16 chars x 2 lines or 20 chars x 2 lines.

The control codes will be specific to a type of display but usually provide the ability to...

- a) send cursor to home position
- b) set cursor attributes on / off / block / underscore
- c) scroll left
- d) scroll right
- e) backspace
- f) blink

3.54 Header 202 - Teach mode control

Format (a)

Transmitted data : [position]

Received data : ACK

Format (b)

Transmitted data : [position] [orientation]

Received data : ACK

[position]

e.g. 1 to 12, 1 to 16

[orientation]

1 to 4 - teaching bills requires the orientation to be known in advance

Puts the device into 'teach' mode. Teach is a mechanism whereby new coins or bills can be 'learnt' by entering a representative sample. On existing Money Controls products this is referred to as Teach-and-run®. Once in teach mode the device should be polled with the 'Request teach status' command to see what is happening.

3.55 Header 201 - Request teach status

Format (a) - default

Transmitted data : [0]

Received data : [no. of coins / bills entered] [status code]

Format (b) - abort teach operation

Transmitted data : [1]

Received data : [no. of coins / bills entered] [status code]

[status code]

252 - teach aborted

253 - teach error

254 - teaching in progress (busy)

255 - teach completed

This command is used to monitor the progress of teach mode. Only when a 'teach completed' status message is received can the operation be deemed successful.

The actual teach mechanism is under the full control of the slave device. It decides when enough coins or bills have been entered.

3.56 Header 200 - Upload coin data

<<< Obsolete command >>>

Transmitted data : [coin position 1] [coin position 2]

[credit code 1] [credit code 2]

[sorter path 2 | sorter path 1]

[sorter path 4 | sorter path 3]

[op code]

[upload 1] [upload 2] [upload 3] [upload 4]...

Received data : ACK or [reply code]

This command is specific to the remote programming of coins.

[op code]

Bit 0 - credit code control

0 = no action

1 = program

Bit 1 - sorter path control

0 = no action

1 = program

Bit 2 - <undefined>

Bit 3 - <undefined>

Bits 4 to 7 - window programming control

0 = calibrate window

1 = delete window

2 to 15 = <undefined>

[reply code]

<<< Refer to Table 5 >>>

This command allows remote re-programming of coin acceptors by transferring a block of calibration data. The credit code and sorter path may be changed as well.

There is support for dual window programming (useful for repeated banks of coins) and also window deletion.

The upload block itself cannot be larger than 245 bytes for each coin.

3.57 Header 199 - Configuration to EEPROM

Transmitted data : <none>

Received data : ACK

This command transfers volatile configuration information for a device from RAM into EEPROM. The information for a coin acceptor could possibly include...

- a) inhibit information
- b) sorter override information
- c) sorter paths

Refer to the product manual for more details.

3.58 Header 198 - Counters to EEPROM

Transmitted data : <none>

Received data : ACK

This command transfers volatile counter information from RAM into EEPROM. The information for a coin acceptor could include...

- a) coin insertion counter
- b) coin accept counter
- c) coin reject counter
- d) error or alarm counter

Refer to the product manual for more details.

3.59 Header 197 - Calculate ROM checksum

Transmitted data : <none>

Received data : [checksum 1] [checksum 2] [checksum 3] [checksum 4]

The method of calculating the ROM checksum is not defined in this document and can be adapted to suit the slave device. A simple ‘unsigned long’ addition can be used as the simplest method with the result displayed as 8 hex digits. The start address and end address is left to the slave device. More powerful devices may choose to calculate a **CRC checksum** using a pre-determined seed value.

There is currently no cctalk mechanism to compare the returned checksum value with a master reference value. That operation must be done by the host.

3.60 Header 196 - Request creation date

Transmitted data : <none>

Received data : [date code LSB] [date code MSB]

The creation date is also known as the...

- manufacturing date
- factory setup date

The date code is stored in a special Money Controls format called RTBY (Relative To Base Year), originally chosen in the mid-Eighties to avoid any Y2K issues.

[date code]

| Bit Positions | | | | | | | |
|---------------|----|----------|---|---------|---|---------|---|
| 15 | 14 | 13 | 9 | 8 | 5 | 4 | 0 |
| Reserved | | Year | | Month | | Day | |
| - | | Relative | | 1 to 12 | | 1 to 31 | |

The year is always stored relative to the PRODUCT_BASE_YEAR which will either be in the product manual or available using the ‘Request base year’ command. The creation date is a maximum of 31 years after the base year.

3.61 Header 195 - Request last modification date

Transmitted data : <none>

Received data : [date code LSB] [date code MSB]

This command returns the last modification date of the product. It is usually changed by remote programming toolkits or PC-based support software.

The date code formatted is detailed under the 'Request creation date' command.

3.62 Header 194 - Request reject counter

Transmitted data : <none>

Received data : [count 1] [count 2] [count 3]

This command returns the total number of reject coins / bills put through a device.

24-bit counter in decimal = [count 1] + 256 * [count 2] + 65536 * [count 3]

Range 0 to 16,777,215

Restrictions on use and likely accuracy will be made clear in the product manual.

3.63 Header 193 - Request fraud counter

Transmitted data : <none>

Received data : [count 1] [count 2] [count 3]

This command returns the total number of fraud coins / bills put through a device.

24-bit counter in decimal = [count 1] + 256 * [count 2] + 65536 * [count 3]

Range 0 to 16,777,215

Restrictions on use and likely accuracy will be made clear in the product manual.

3.64 Header 192 - Request build code

Transmitted data : <none>

Received data : ASCII

The product build code is returned. No restriction on format.

3.65 Header 191 - Keypad control

Transmitted data : [keypad code]

Received data : [cursor position] [char 1] [char 2] [char 3]...

This command allows the remote execution of a keypad and display control system. The code sent is used to simulate which button was pressed on the keypad and the message sent back is the display string together with a current cursor position.

For displays that support more than one line a null byte can be used in the string to indicate line breaks.

[keypad code]

0 - return current display message

1 - press button 1

2 - press button 2

3 - press button 3

4 - press button 4

etc.

[cursor position]

0 - cursor off or not used

1 to 255 - current cursor position

3.66 Header 190 - Request payout status

<<< Obsolete command >>>

Format (a)

Transmitted data : <none>

Received data : [events]

[no. of coins paid out LSB] [no. of coins paid out MSB]

[status code]

Format (b)

Transmitted data : <none>

Received data : [events]

[coin value paid out LSB] [coin value paid out MSB]

[status code]

This command is used to monitor the progress of a payout sequence.

[events]

0 (reset or power-up condition)

1 to 255 - event counter

The event counter is incremented on receipt of a valid hopper payout command and wraps around from 255 to 1. This is a security mechanism to prevent unnecessary retries if a comms error occurs.

[status code]

250 - error, payout blocked (coin over exit sensors)

251 - error, payout timeout (no coins detected)

252 - error, payout jammed (over-current trip)

253 - payout incomplete (insufficient change / incorrect hopper no.)

254 - paying out (busy)

255 - payout completed

3.67 Header 189 - Modify default sorter path

Transmitted data : [default path]

Received data : ACK

[default path]

e.g. 1 to 4, 1 to 8

This command allows the default sorter path on a coin acceptor to be changed. If there is an active override on the current coin sorter path then it will be routed to the default path.

The product manual should make clear whether this change is permanent (stored in non-volatile memory) or temporary (stored in RAM).

3.68 Header 188 - Request default sorter path

Transmitted data : <none>

Received data : [default path]

This command reads the default sorter path on a coin acceptor.

See the 'Modify default sorter path' command for more details.

3.69 Header 187 - Modify payout capacity

Format (a)

Transmitted data : [no. of coins LSB] [no. of coins MSB]

Received data : ACK

Format (b)

Transmitted data : [hopper no.] [no. of coins LSB] [no. of coins MSB]

Received data : ACK

This command sets the maximum number of coins a payout device can hold. Multiple hoppers are supported if they exist.

3.70 Header 186 - Request payout capacity

Format (a)

Transmitted data : <none>

Received data : [no. of coins LSB] [no. of coins MSB]

Format (b)

Transmitted data : [hopper no.]

Received data : [no. of coins LSB] [no. of coins MSB]

This command requests the maximum number of coins a payout device can hold. Multiple hoppers are supported if they exist.

3.71 Header 185 - Modify coin id

Transmitted data : [coin position] [char 1] [char 2] [char 3]...

Received data : ACK

[coin position]

e.g. 1 to 12, 1 to 16

Some coin acceptors can store an identification string alongside the normal validation parameters for each coin. Refer to the product manual for details.

Refer to Appendix 3.1 for coin naming information.

3.72 Header 184 - Request coin id

Transmitted data : [coin position]

Received data : [char 1] [char 2] [char 3]...

Refer to the 'Modify coin id' command for more details.

3.73 Header 183 - Upload window data

Format (a) - program coin

Transmitted data : [0] [coin position]

<variable>

Received data : ACK

Format (b) - modify credit code

Transmitted data : [1] [coin position] [credit code]

Received data : ACK

Format (c) - delete coin

Transmitted data : [2] [coin position]

Received data : ACK

Format (d) - program token

Transmitted data : [3] [token position]

<variable>

Received data : ACK

Format (e) - delete token

Transmitted data : [4] [token position]

Received data : ACK

This command is used for the remote programming of coins or tokens.

[coin position]

e.g. 1 to 12, 1 to 16

[token position]
e.g. 1 to 12, 1 to 16

The variable block of data sent to program a coin or token will be manufacturer specific.

Currently there is no mechanism provided for changing the credit codes of tokens as tokens are usually substituted into coin window space and inherit their attributes.

Some or all of the above features may be disabled for security reasons.

3.74 Header 182 - Download calibration info

Transmitted data : <none>
Received data : <variable>

This command is used to support the remote coin programming operation. No further details are given here.

3.75 Header 181 - Modify security setting

Transmitted data : [coin / bill position] [security setting]
Received data : ACK

[coin position]
e.g. 1 to 12, 1 to 16

[security setting]
0 - default setting (nominal performance)
1 to 7 - gradually increase fraud rejection (7 steps)
255 to 249 - gradually increase true acceptance (7 steps)
8 to 248 - undefined

This command allows a validator's performance to be finely tuned. On all known devices there is a trade-off between fraud rejection and true acceptance.

The product manual should make clear whether this change is permanent (stored in non-volatile memory) or temporary (stored in RAM).

3.76 Header 180 - Request security setting

Transmitted data : [coin / bill position]
Received data : [security setting]

Refer to the 'Modify security setting' command for more details.

3.77 Header 179 - Modify bank select

Transmitted data : [bank no.]

Received data : ACK

[bank no.]

0 - default bank

1 to 255 - alternative banks

Some devices can support multiple banks of coins / bills subject to the condition of only a single bank being enabled (active) at any one time. This command allows the host controller to switch between banks. Assuming a typical device operates with 16 coins or bills, this command expands the potential capability to $16 \times 256 = 4,096$ coins or bills, though not all can be accepted concurrently.

Coins or bills within a bank can be controlled with the 'Modify inhibit status' command.

3.78 Header 178 - Request bank select

Transmitted data : <none>

Received data : [bank no.]

Refer to the 'Modify bank select' command for details.

3.79 Header 177 - Handheld function

Transmitted data : [XX | mode | function] <variable>

Received data : <variable>

[mode]

0 to 3 - operating mode

[function]

0 to 15 - operating function

This command may be used to support simple handheld toolkits (non-PC based, low processing power) which send simple 'mode / function' sequence commands to the slave device. The response may be an ACK or a number of data bytes.

This command will be product and manufacturer specific and may not be implemented at all. Some devices have useful debugging features which can be accessed through this command.

See 'BACTA Token Selection' in Part 3 of the documentation for an example of use.

3.80 Header 176 - Request alarm counter

Transmitted data : <none>

Received data : [alarm count]

This command returns the number of alarm events since the last request was sent (i.e. it is cleared on reading). It is only used on products which support an alarm output line.

3.81 Header 175 - Modify payout float

Format (a)

Transmitted data : [no. of coins LSB] [no. of coins MSB]

Received data : ACK

Format (b)

Transmitted data : [hopper no.] [no. of coins LSB] [no. of coins MSB]

Received data : ACK

This command sets the working 'float' level for a payout device. Multiple hoppers are supported if they exist.

3.82 Header 174 - Request payout float

Format (a)

Transmitted data : <none>

Received data : [no. of coins LSB] [no. of coins MSB]

Format (b)

Transmitted data : [hopper no.]

Received data : [no. of coins LSB] [no. of coins MSB]

This command requests the working 'float' level for a payout device. Multiple hoppers are supported if they exist.

3.83 Header 173 - Request thermistor reading

Transmitted data : <none>

Received data : [thermistor value]

Previously : Some products use a thermistor to provide an approximate method of determining the ambient temperature. This command returns the raw thermistor reading as a byte.

This command is no longer restricted to thermistor temperature measurement – more accurate methods are commonly available. The format of the return data is now specified as 'degrees Celsius' in 2's complement format. This gives a range of -128°C to +127°C.

Older Money Controls products return thermistor data in a 'raw' format as described below. This format is now obsolete.

The thermistor is placed in a simple voltage divider network biased such that the value of 128 indicates a temperature of 25°C. A value higher than 128 means a temperature above 25°C and a value lower than 128 means a temperature below 25°C. The thermistor circuit consists of an analogue input voltage to the microcontroller, with a 10K pull-down to GND and a 10K NTC thermistor pull-up to Vref. As the temperature goes up, so does the input voltage. The signal is reasonably linear around 25°C but curves at the extremes. This formula can be used to calculate the approximate temperature from the thermistor reading.

`temperature = (((thermistor value - 128) / 102 * 45) + 25) °C`

3.84 Header 172 - Emergency stop

Transmitted data : <none>

Received data : [payout coins remaining]

This command immediately halts the payout sequence and reports back the number of coins which failed to be paid out.

3.85 Header 171 - Request hopper coin

Transmitted data : <none>

Received data : ASCII

This command returns the name of the coin that the hopper can pay out.

Refer to Appendix 3.1 for coin naming information.

3.86 Header 170 - Request base year

Transmitted data : <none>

Received data : [char 1] [char 2] [char 3] [char 4]

The product base year (see PRODUCT_BASE_YEAR in 'Request creation date' and 'Request last modification date' commands) is returned as a 4 character ASCII string.

e.g. '1999', '2000'.

3.87 Header 169 - Request address mode

Transmitted data : <none>

Received data : [address mode]

This command returns the cctalk addressing mode to help with automatic re-configuration of cctalk peripherals. Its use is informational only.

[address mode]

Bit mask :

B0 - Address is stored in ROM

- B1 - Address is stored in RAM
- B2 - Address is stored in EEPROM or NV memory
- B3 - Address selection via interface connector
- B4 - Address selection via PCB links
- B5 - Address selection via switch
- B6 - Address may be changed with serial commands (volatile)
- B7 - Address may be changed with serial commands (non-volatile)

Any bits may be set according to the operating mode of the device.
[0] is returned to indicate another type of addressing mode.

3.88 Header 168 - Request hopper dispense count

Transmitted data : <none>
Received data : [count 1] [count 2] [count 3]

The dispense counter records the number of coins dispensed by the hopper.

count 1 = LSB, count 3 = MSB

24-bit counter in decimal = [count 1] + 256 * [count 2] + 65536 * [count 3]
Range 0 to 16,777,215

3.89 Header 167 - Dispense hopper coins

Format (a) - Money Controls 'SCH2' version
Transmitted data : <variable> [no. of coins]
Received data : [event counter] or NAK

Format (b) - Money Controls 'SCH1' version
Transmitted data : <variable> [no. of coins]
Received data : ACK or NAK

This command is used to securely dispense between 1 and 255 coins from a hopper. The variable data represents special security codes which have to be correct for a coin payout to be successful. The security algorithm is not given in this document.

The event counter returned is the post-increment value. Refer to the 'Request hopper status' command for more details.

3.90 Header 166 - Request hopper status

Transmitted data : <none>
Received data : [event counter] [payout coins remaining]
[last payout : coins paid] [last payout : coins unpaid]

[event counter]
0 (power-up or reset condition)
1 to 255 - event counter

The event counter is incremented every time a valid dispense command is received. When the event counter is at 255 the next event causes the counter to change to 1. The only way for the counter to be 0 is at power-up or reset.

The [payout coins remaining], [last payout : coins paid] and [last payout : coins unpaid] fields are updated appropriately during and after coin payout.

Refer to the SCH2 hopper manual for more details.

3.91 Header 165 - Modify variable set

Transmitted data : <variable>

Received data : ACK

This command modifies variable data on the slave device. Refer to the product manual for more details.

3.92 Header 164 - Enable hopper

Transmitted data : [enable code]

Received data : ACK

[enable code]

165 - enable hopper payout

not 165 - disable hopper payout

This command must be used to enable a hopper before paying out coins.

The value 165 is 'A5' in hex and '10100101' in binary.

3.93 Header 163 - Test hopper

Format (c) - Money Controls 'SCH3' version

Transmitted data : <none>

Received data : [hopper status register 1] [hopper status register 2]
[hopper status register 2]

Format (b) - Money Controls 'SCH2' version

Transmitted data : <none>

Received data : [hopper status register 1] [hopper status register 2]

Format (a) - Money Controls 'SCH1' version

Transmitted data : <none>

Received data : [hopper status register 1]

This command reports back various operating and error flags from the hopper and is the equivalent of the 'Perform self-check' command in coin / bill acceptors.

[hopper status register 1]

Bit mask :

- Bit 0 - Absolute maximum current exceeded
- Bit 1 - Payout timeout occurred
- Bit 2 - Motor reversed during last payout to clear a jam
- Bit 3 - Opto fraud attempt, path blocked during idle
- Bit 4 - Opto fraud attempt, short-circuit during idle
- Bit 5 - Opto blocked permanently during payout
- Bit 6 - Power-up detected
- Bit 7 - Payout disabled

[hopper status register 2]

Bit mask :

- Bit 0 - Opto fraud attempt, short-circuit during payout
- Bit 1 - Single coin payout mode
- Bit 2 - Use other hopper for change
- Bit 3 - Opto fraud attempt, finger / slider mis-match
- Bit 4 - Motor reverse limit reached
- Bit 5 - Inductive coil fault
- Bit 6 - NV memory checksum error
- Bit 7 - PIN number mechanism

[hopper status register 3]

Bit mask :

- Bit 0 - Power-down during payout
- Bit 1 - Unknown coin type paid
- Bit 2 - PIN number incorrect
- Bit 3 - Incorrect cipher key
- Bit 4 - < Reserved >
- Bit 5 - < Reserved >
- Bit 6 - < Reserved >
- Bit 7 - < Reserved >

1 = condition on, 0 = condition off

3.93.1. Flag Explanation

3.93.1.1. Absolute maximum current exceeded

Payout stopped because a maximum threshold current was exceeded. This is the software equivalent of a protection fuse and may indicate an irrecoverable jam or a motor bridge fault. The flag must be cleared with a software reset prior to next payout but if the fault is permanent then it may not be possible to clear this condition.

3.93.1.2. Payout timeout occurred

Indicates the payout operation terminated after a specified timeout period with no coins visible on the exit sensor. This could be because the hopper was empty.
Warning flag only.

3.93.1.3. Motor reversed during last payout to clear a jam

A motor jam was detected and the hopper attempted a reverse to clear it. Warning flag only.

3.93.1.4. Opto fraud attempt, path blocked during idle

The hopper exit opto saw a blockage outside a payout operation. This could be due to a coin stuck in the exit path or a deliberate fraud attempt. The flag must be cleared with a software reset prior to next payout.

3.93.1.5. Opto fraud attempt, short-circuit during idle

The hopper exit opto saw a short-circuit outside a payout operation. This is most likely due to shining light directly into the exit opto. The flag must be cleared with a software reset prior to next payout.

3.93.1.6. Opto blocked permanently during payout

The hopper exit opto saw a blockage for too long a time while paying out coins. This could be due to a coin stuck in the exit path or a deliberate fraud attempt. The flag must be cleared with a software reset prior to next payout.

3.93.1.7. Power-up detected

This flag indicates that the hopper has had power applied to it. It is cleared by a software reset and so can be used to distinguish between a software reset and a hardware reset / power supply removal. Warning flag only.

3.93.1.8. Payout disabled

The hopper is always disabled after a power-up or reset. The flag must be cleared with an 'Enable hopper' command prior to next payout.

3.93.1.9. Opto fraud attempt, short-circuit during payout

The hopper exit opto saw a short-circuit while paying out coins. This is most likely due to shining light directly into the exit opto. The flag must be cleared with a software reset prior to next payout.

3.93.1.10. Single coin mode

This flag indicates the hopper is working in single coin mode and will only respond to commands to dispense one coin at a time. This method is slower but achieves maximum security as there is full handshaking on each coin paid out. Status flag only.

3.93.1.11. Use other hopper for change

Accumulator mode : This flag indicates the hopper cannot dispense any more coins and a secondary hopper must be used to complete the dispense operation. Status flag only.

3.93.1.12. Opto fraud attempt, finger / slider mis-match

Some hoppers are fitted with sensors on the fingers or sliders used to eject coins cleanly. If a coin is seen leaving the exit optos but no signal is seen on the finger or slider then this error flag is set as it could be a possible fraud attempt. The flag must be cleared with a software reset prior to next payout.

3.93.1.13. Motor reverse limit reached

If the number of sequential motor reverses exceeds a preset limit then the hopper dispense is aborted and this flag set. It is likely that there is a permanent coin jam in the hopper. The flag must be cleared with a software reset prior to next payout.

3.93.1.14. Inductive coil fault

Accumulator mode : This flag indicates a fault has been detected with the coil used to distinguish between different coin types. The flag must be cleared with a software reset prior to next payout but if the fault is permanent then it may not be possible to clear this condition.

3.93.1.15. NV memory checksum error

An error has occurred with the NV memory which means the values of the coin paid and unpaid counters may not be correct. Refer to the product manual for appropriate action.

3.93.1.16. PIN number mechanism

This flag indicates that the PIN number mechanism is enabled and that a PIN has to be entered using command header 218 before any coins can be paid out. Status flag only.

3.93.1.17. Power-down during payout

If power is lost during a payout operation then this flag will be set. The values of the paid and unpaid counters will indicate what happened just prior to power being lost. The flag must be cleared with a software reset prior to next payout.

3.93.1.18. Unknown coin type paid

Accumulator mode : This flag indicates that the coin just paid was not a recognised type. The hopper stops immediately. Either an illegal coin type has been placed in the hopper or there is a problem with the coin sensing. The flag must be cleared with a software reset prior to next payout.

3.93.1.19. PIN number incorrect

The hopper dispense operation failed because the PIN number protection mechanism has been enabled (using the 'Enter new PIN number' command) - see PIN number mechanism flag - but the 'Enter PIN number' command has not yet been sent or the number sent was incorrect. The flag must be cleared with a software reset prior to next payout.

3.93.1.20. Incorrect cipher key

If the hopper uses encryption and an incorrect cipher key sent then the hopper dispense operation will fail and this flag set. The flag must be cleared with a software reset prior to next payout.

Header 162 - Modify inhibit and override registers

Transmitted data : [current : inhibit mask 1] [current : inhibit mask 2]
 [current : sorter override bit mask]
 [next : inhibit mask 1] [next : inhibit mask 2]
 [next : sorter override bit mask]
Received data : ACK

For coin acceptors this command...

- a) sets inhibits and overrides in one operation (see also the 'Modify inhibit status' command and the 'Modify sorter override status' command)
- b) sets both a 'current' value and a 'next coin' value

The benefit of using this command is that it allows precise coin-by-coin control of the coin acceptor and provides a means of tackling the inherent latency in serial operation. If the next coin is always disabled, the validator will only accept one coin at a time. After each credit (strictly speaking an attempted accept sequence) the host software can request another coin and thus control the overall accept rate. If the next coin overrides are always active, the validator will only route one coin at a time to a payout tube - all other coins will go to the cashbox. The host software can thus maintain a precise fill level in any tube.

3.94 Header 161 - Pump RNG

Transmitted data : <variable>
Received data : ACK

This command 'pumps' the random number generator of the slave device with a set of random numbers and is part of the hopper dispense encryption algorithm.

No further details are given here.

3.95 Header 160 - Request cipher key

Transmitted data : <none>
Received data : <variable>

This command requests a cipher key from the slave device and is part of the hopper dispense encryption algorithm.

No further details are given here.

3.96 Header 159 - Read buffered bill events

Transmitted data : <none>

Received data : [event counter]
[result 1A] [result 1B]
[result 2A] [result 2B]
[result 3A] [result 3B]
[result 4A] [result 4B]
[result 5A] [result 5B]

This command returns a history of bill events in a similar way to that of a coin acceptor. Refer to the 'Read buffered credit or error codes' command for more details.

For an explanation of the bill event codes...

<<< Refer to Table 7 >>>

3.97 Header 158 - Modify bill id

Transmitted data : [bill type] [char 1] [char 2] [char 3]...

Received data : ACK

[bill type]
e.g. 1 to 16

Some bill validators can store an identification string alongside the normal validation parameters for each bill. Refer to the product manual for details.

A 7 character identification code is used...

[C][C][V][V][V][V][I]

CC = Standard 2 letter country code e.g. GB for the U.K. (Great Britain)

VVVV = Bill value in terms of the country scaling factor

I = Issue code. Starts at A and progresses B, C, D, E...

See Appendix 10 for country codes.

3.98 Header 157 - Request bill id

Transmitted data : [bill type]

Received data : [char 1] [char 2] [char 3]...

Refer to the 'Modify bill id' command for more details.

3.99 Header 156 - Request country scaling factor

Transmitted data : [country char 1] [country char 2]

Received data : [scaling factor LSB] [scaling factor MSB] [decimal places]

This command requests the scaling factor and decimal places for the standard country code provided.

If all the return bytes are zero then that country code is not supported.

3.100 Header 155 - Request bill position

Transmitted data : [country char 1] [country char 2]

Received data : [position mask 1] [position mask 2]

This command can be used in bill acceptors to locate the inhibit mask of a given currency based on its country code. The inhibit mask ties up with the 'Modify inhibit status' command for inhibiting individual bills.

If this data is used directly as the new inhibit mask then the currency selected will be enabled and all other currencies inhibited.

3.101 Header 154 - Route bill

Transmitted data : [route code]

Received data : ACK or [error code]

This command controls routing of a bill held in an escrow.

[route code]

0 - return bill

1 - send bill to cashbox / stacker

255 - extend escrow timeout

[error code]

254 - escrow is empty

255 - failed to route bill

Route code 255 resets the default escrow timeout to prevent the note being returned to the customer. Although the escrow timeout is usually quite long (30s or more) there may be a situation where the host machine needs more time before a routing decision is made.

3.102 Header 153 - Modify bill operating mode

Transmitted data : [mode control mask]

Received data : ACK

This command controls whether various product features are used.

[mode control mask]

B0 - stacker

B1 - escrow

0 = do not use, 1 = use

3.103 Header 152 - Request bill operating mode

Transmitted data : <none>

Received data : [mode control mask]

Refer to the 'Modify bill operating mode' command.

3.104 Header 151 - Test lamps

Transmitted data : [lamp no.] [lamp control]

Received data : ACK

This command is a diagnostic tool for products that support lamps. On bill validators, front-panel lamps are often used to guide the user on note insertion.

[lamp no.]

1, 2, 3 etc.

[lamp control]

0 - automatic mode, allow device to control lamp

1 - manual mode, force lamp off

2 - manual mode, force lamp on

3.105 Header 150 - Request individual accept counter

Transmitted data : [bill type]

Received data : [count 1] [count 2] [count 3]

Some bill validators support the individual counting of different bill types. This command returns the number of bills accepted of a given type. The type is that reported by the 'Read buffered bill events' command.

count 1 = LSB

24-bit counter in decimal = [count 1] + 256 * [count 2] + 65536 * [count 3]

Range 0 to 16,777,215

3.106 Header 149 - Request individual error counter

Transmitted data : [error type]

Received data : [count 1] [count 2] [count 3]

Some bill validators support the individual counting of different error types. This command returns the number of errors recorded of a given type.

[error type]

See Table 7. If a particular error is not counted then there should be no reply.

count 1 = LSB

24-bit counter in decimal = [count 1] + 256 * [count 2] + 65536 * [count 3]

Range 0 to 16,777,215

3.107 Header 148 - Read opto voltages

Transmitted data : <none>

Received data : <variable>

This command returns a series of scaled voltages for a device using optos (e.g. a bill validator) rather than the blocked / clear indication which would be returned by the 'Read opto states' command.

Voltage measurements are assumed to be made through a 8-bit A/D converter with a full-scale reading at +5V. This gives a resolution of 19.6mV.

| Count | Voltage |
|-------|---------|
| 255 | 5.00 |
| 192 | 3.76 |
| 128 | 2.51 |
| 64 | 1.25 |
| 0 | 0.00 |

3.108 Header 147 - Perform stacker cycle

Transmitted data : <none>

Received data : ACK or [error code]

[error code]

254 - stacker fault

255 - stacker not fitted

This command executes 1 cycle of the stacker on a bill validator for diagnostic purposes. The ACK is returned after the cycle completes.

3.109 Header 146 - Operate bi-directional motors

Transmitted data : [motor mask] [direction flags] [speed]

Received data : ACK

This command is a diagnostic tool for testing the motors.

[motor mask]

Each bit represents a motor. 0 = off, 1 = on.

[direction flags]

Each bit represents a motor direction. 0 = backwards, 1 = forwards.

[speed]

0 - default speed

1 to 255 - relative speed number. 1 = slowest, 255 = fastest.

3.110 Header 145 - Request currency revision

Format (a)

Transmitted data : <none>

Received data : ASCII

Format (b)

Transmitted data : [country char 1] [country char 2]

Received data : ASCII

If no parameters are sent then a general currency revision is returned. Otherwise, 2 ASCII characters identifying the country of interest can be sent to determine a revision code specific to that country.

If the country identifier is not recognised then the string 'Unknown' is returned.

3.111 Header 144 - Upload bill tables

Transmitted data : [block] [line] [data 1] [data 2]... [data 128]

Received data : ACK

This commands sends new bill table information into a validator in a manufacturer-neutral format. The data is split into blocks and lines. There are 128 bytes per line, 256 lines per block, up to a maximum of 256 blocks. This gives a total capacity of $256 \times 256 \times 128 = 8$ Mbytes.

Lines shorter than 128 bytes can be sent since each message packet contains a length descriptor.

There is no reference to bill type in the data structure - it is assumed that this is represented internally.

3.112 Header 143 - Begin bill table upgrade

Transmitted data : <none>

Received data : ACK

This command initiates a bill table upgrade.

3.113 Header 142 - Finish bill table upgrade

Transmitted data : <none>

Received data : ACK or NAK

This command terminates a bill table upgrade.

3.114 Header 141 - Request firmware upgrade capability

Transmitted data : <none>

Received data : [firmware options]

[firmware options]

0 - firmware in ROM / EPROM

1 - firmware in FLASH / EEPROM with upgrade capability

Only firmware of type 1 can be upgraded remotely.

3.115 Header 140 - Upload firmware

Transmitted data : [block] [line] [data 1] [data 2]... [data 128]

Received data : ACK

This general purpose command can be used to upgrade the firmware in a validator.

The format is the same as the 'Upload bill tables' command.

3.116 Header 139 - Begin firmware upgrade

Transmitted data : <none>

Received data : ACK

This command initiates a firmware upgrade.

3.117 Header 138 - Finish firmware upgrade

Transmitted data : <none>

Received data : ACK

This command terminates a firmware upgrade.

3.118 Header 137 - Switch encryption code

Transmitted data : [sec 2 | sec 1] [sec 4 | sec 3] [sec 6 | sec 5]

Received data : ACK

[sec N]

BCD security digit in the range 0 to 9

The full encryption code is 6 digits long, e.g. 123456

When the cctalk encryption layer is being used, this command allows the encryption code or key to be switched to a new value. Regular switching of the encryption code massively increases the security of the communications link.

The new security code takes effect **after** the ACK is returned.

Encryption code changes are volatile. The 'Store encryption code' command can be used to make the change permanent.

3.119 Header 136 - Store encryption code

Transmitted data : <none>

Received data : ACK

This command stores the current encryption code in NV memory. At the next power up, this is the encryption code which needs to be used.

3.120 Header 135 - Set accept limit

Transmitted data : [no. of coins]

Received data : ACK

Some applications such as gaming machines require no more than say 3 or 5 coins to be accepted per game play. For a serial coin acceptor this means sending a command to inhibit coin acceptance after a specified number of coins has been entered. When coin throughput is high there is a chance further coins will be accepted due to the latency of serial itself. New coins can only be detected at the credit polling interval and by that time more coins could have passed the accept gate.

Refer to header 231, 'Modify inhibit status' and header 162, 'Modify inhibit and override registers'. The latter was introduced for coin by coin control but it is not suitable for fast acceptance of a stream of coins.

Set accept limit has a parameter 'no. of coins' which determines how many coins are accepted before the coin acceptor inhibits itself. After self-inhibit, no further coins can be accepted until another 'Set accept limit' command is sent. During self-inhibit, cctalk event codes 'Inhibited coin' will be returned for each coin entered. It is possible to switch off the self-inhibit mechanism by sending 'no. of coins' equal to zero.

Self-inhibit operates independently of the modify inhibit status register used in cctalk command 231. All coins are inhibited, regardless of type. Therefore this command is really only of use in single-coin coin acceptors. Currently there are no plans for a 'Set accept value' command which works as a device-side totaliser.

3.121 Header 134 - Dispense hopper value

Transmitted data : [sec 1] [sec 2] [sec 3] [sec 4]
 [sec 5] [sec 6] [sec 7] [sec 8]
 [coin value LSB] [coin value MSB]
Received data : [event counter] or NAK

[coin value]

Range 0 to 65,535.

This command is used to securely dispense a coin value from an accumulator hopper. For a discussion of an 'accumulator hopper' versus a 'discriminator hopper' refer to the glossary. The coin value is based on the lowest unit in that currency, e.g. pence or cents.

The variable data represents special security codes which have to be correct for a coin payout to be successful. The security algorithm is not given in this document. An 'unencrypted' hopper ignores the security codes and always dispenses coins.

The event counter returned is the post-increment value. Refer to the 'Request hopper polling value' command for more details.

3.122 Header 133 - Request hopper polling value

Transmitted data : <none>

Received data : [event counter]
 [payout value remaining LSB] [payout value remaining MSB]
 [last payout : coin value paid LSB] [last payout : coin value paid MSB]
 [last payout : coin value unpaid LSB] [last payout : coin value unpaid MSB]

[event counter]

0 (power-up or reset condition)

1 to 255 - event counter

The event counter is incremented every time a valid dispense command is received. When the event counter is at 255 the next event causes the counter to change to 1. The only way for the counter to be 0 is at power-up or reset.

The [payout value remaining], [last payout : coin value paid] and [last payout : coin value unpaid] fields are updated appropriately during and after coin payout.

When [payout value remaining] = 0, which means both the LSB and MSB bytes are zero, the payout operation has stopped and the paid / unpaid values show whether it was successful. The flags status register (see the Test hopper command) can be checked to determine the status of the hopper after payout is complete and to see if any errors occurred.

3.123 Header 132 - Emergency stop value

Transmitted data : <none>

Received data : [payout value remaining LSB] [payout value remaining MSB]

This command immediately halts the payout sequence and reports back the value of coins which failed to be paid out.

3.124 Header 131 - Request hopper coin value

Transmitted data : [coin type]

Received data : 6 x ASCII chars
[coin value LSB] [coin value MSB]

[coin type]

1 to N

(N = number of different coin types that can be dispensed by the hopper)

This command returns the name of the coin as well as the coin value in binary.

Refer to Appendix 3.1 for coin naming information.

3.125 Header 130 - Request indexed hopper dispense count

Transmitted data : [coin type]

Received data : [count 1] [count 2] [count 3]

[coin type]

1 to N

(N = number of different coin types that can be dispensed by the hopper)

The dispense counter records the number of each coin type dispensed by the hopper.

count 1 = LSB, count 3 = MSB

24-bit counter in decimal = [count 1] + 256 * [count 2] + 65536 * [count 3]

Range 0 to 16,777,215

3.126 Header 129 – Read barcode data

Transmitted data : <none>

Received data : ASCII

When bill event code 20 is polled by a host system talking to a bill validator, a coupon has been inserted with a conforming barcode pattern. This barcode can be read as an ASCII string. The barcode data will remain (and can be read at any time) until a new coupon is inserted and another bill event code 20 is polled.

The ASCII data may contain any alpha-numeric characters applicable to the barcode formats supported by the device. For example, the interleaved 2 of 5 format returns 18 numeric characters e.g. '213866515856379505'. The interpretation of the barcode is entirely down to the host system – most barcodes are linked to back office systems.

If the barcode format supports a checksum character then this should be returned as part of the ASCII data.

3.127 Header 4 - Request comms revision

Transmitted data : <none>

Received data : [cctalk level] [major revision] [minor revision]

This command requests the cctalk level number and the major / minor revision numbers of the comms specification. This is read separately to the main software revision number for the product which can be obtained with a 'Request software revision' command.

The revision numbers should tie up with those at the top of this specification document.

The cctalk level number is used to track changes to the serial comms library in that particular product.

For example, the first release of a product conforming to this specification document at issue 4.0 should return [1] [4] [0]

3.128 Header 3 - Clear comms status variables

Transmitted data : <none>

Received data : ACK

This command clears the comms status variables (cumulative single byte event counters). See 'Request comms status variables' command for more details.

3.129 Header 2 - Request comms status variables

Transmitted data : <none>

Received data : [rx timeouts] [rx bytes ignored] [rx bad checksums]

There are 3 cumulative single byte event counters (the value 255 wraps around to 0) that can be requested with this command. For the data to be useful, the counters should be cleared first with the 'Clear comms status variables' command.

[rx timeouts] - cumulative event counter

This is the number of times the slave device has timed out on receiving data. This should be zero for a good communication link and a correctly implemented communication algorithm. The slave device should count and ignore incorrectly addressed messages and unrecognised headers without timing out. It should also handle the MDCES commands without registering a timeout. Since the length of all messages is contained within the message structure or is known in advance then this should not be a problem.

[rx bytes ignored] - cumulative event counter

If a long message is sent to the slave device, not all of which can be stored in the receive buffer, then the number of bytes lost is added to this counter. Note that the slave device should still be able to calculate the checksum of a correctly addressed message even if some of the receive data is not stored. However if the encryption layer is used the entire receive data will need to be stored.

This counter provides a mechanism for host software to determine the size of the slave receive buffer. A special 'Simple poll' command can be sent padded out with 252 bytes of dummy data. The size of the receive buffer = 257 - [rx bytes ignored] assuming that the 'bytes ignored' is non-zero and that the slave device stores the entire message packet.

[rx bad checksums] - cumulative event counter

This counter is incremented each time a receive message is discovered with an incorrect checksum **and a valid slave address**. This variable can be monitored for signs of a noisy communication link.

A host machine could make use of this command to evaluate the amount of electrical noise on the serial bus. It could check these variables every hour for instance.

3.130 Header 1 - Reset device

Transmitted data : <none>

Received data : ACK

This command forces a *soft* reset in the slave device. It is up to the slave device what action is taken on receipt of this command and whether any internal house-keeping is done. The action may range from a jump to the reset vector to a forced physical reset of the processor and peripheral devices. This command is worth trying before a hard reset (or power-down where there is no reset pin) is performed.

The slave device should return an ACK immediately prior to resetting and allow enough time for the message to be sent back in full.

The host device should wait an appropriate amount of time after issuing a 'Reset device' command before sending the next command.